




FLAME ARRESTER

Model: FLIL-30

DEFLAGRATION PROOF IN-LINE

INTRODUCTION

 **The model FLIL-30** inline detonation flame arrester is designed, manufactured and tested according to API 2000, British Standard Specification Code BS7244 and ISO 16852. The units are passive devices with no moving parts. The FLEL-30 detonation flame arresters provide protection against flame propagation in piping systems that are manifolded or have long runs. The arresters are designed to stop an ignited flammable vapor mixture traveling at subsonic or supersonic vapor velocities. They are also designed to protect against continuous burning against the SS316L flame cell.

Operating Temperature @ Pressure

FLEL- 40 / DN 50 ~ DN 300

+ 60 (=140°F) @ 0.11 Mpa


 **Body Materials** Nodular Iron, Cast Steel, SS304, SS316, SS316L with various trims
(Different materials available on request)

 **Sizes range** DN 50 ~ DN 300 with ASME 150Lb flanges
(Different connections available on request)


 **Rules & Certifications** API 2000, BS7244 / ISO 16852
Flame cell : NEC group D (=IIA), group C(=IIB3) and group B(=IIC), ETC.

 **Optimum / optional Design & Arrangements** Stem Jacket type, Steam Tracing type

APPLICATION



OUTLINE DRAWING



DIMENSION TABLE

SIZE	2"	3"	4"	6"	8"	10"	12"
N.D	50	80	100	150	200	250	300
L	396	430	502	522	592	770	810
Approx. H	247	276	335	408	488	639	705

NOTE Standard Connection(ASME 150Lb flange) and JIS or different types are available upon request.

COMPONENT MATERIAL

ITEM NO	COMPONENT	CARBON STEEL	STAINLESS STEEL
1	BODY	CAST or WELDED CARBON STEEL	CAST or WELDED STAINLESS STEEL
2	ELEMENT	SS316L	
3	ELEMENT HOUSING	SS304	SS304/SS316L
4	GASKET	PTFE	
5	STUD BOLT/NUT	A193-B7 / A194-2H or STAINLESS STEEL	
STANDARD PAINTING		IN-OUT SIDE EPOXY 150 MICRON WITHOUT STAINLESS STEEL & ALUMINIUM PART	

MAINTENANCE

- ⓘ Periodic inspection and maintenance is required. The cell assembly can be removed for cleaning purposes.
- ⓘ Cleaning can be accomplished by dipping the entire cell assembly into an appropriate solvent.
- ⓘ Care should be taken not to damage the cell openings as such deformations hamper the flow through the cell.
- ⓘ The gaskets should be inspected and replaced if necessary.